



Assault Wall Mounts/Hangers

Threaded
Insert
Keyhole
Slot



 x2
Slot T-Nut

 x2
#10-32 x 5/8" Screw

Part Number

TGW-BM, TGW-FH, TGW-GHM
TGW-SGSH-12, TGW-SGSH-20, TGW-SGSH-410
TGW-MH-9, TGW-MH-9S, TGW-MH-40, TGW-MH-45
TGW-MH-AK47, TGW-MH-AR15
TGW-MM-AR15, TGW-MM-AK47

Tools Required

Slat Wall Mounting:

- Allen Wrench

Wall Mounting:

- Allen Wrench
- Drill
- Hammer
- Level

Mounting Options

Option 1: Assault Wall Slat Wall Mounting

1. Locate the included mounting hardware.
2. Insert each 5/8" screw into a T-nut, ensuring the screw head sits flush inside the T-nut.
3. On the back of the mount, locate the pre-installed silver threaded inserts.
4. Thread the screw/T-nut assemblies by hand into the silver inserts.
5. Using an Allen wrench, tighten until:
 - The back of the T-nut sits flush against the mount
 - The T-nut no longer rocks or spins freely
 -  Do not overtighten.
6. From the edge of the panel—or via an accessory access cutouts (if multiple panels installed), slide the assembled mount into your desired position on the Assault Wall panel.

Option 2: Direct Wall Mounting (supplied hardware won't be needed)

1. Position your screws so the heads contact the upper portion of the mount's built-in keyhole slots.
2. Mark your mounting locations on the wall.
3. If no wall stud is available, install your preferred drywall anchors at the marked locations.
4. Install your user-supplied screws into the wall studs or anchors, leaving the screw heads slightly standing off of the wall.
5. Slide the mount onto the installed screws until fully seated.

Contact Us

Still Have Questions?



sales@doubletapind.com



812-274-4130



www.doubletapind.com