






STRONGHOLD 360-DEGREE BALL HEAD

Part Number

TRI-BH



Installing the Ball Head

1. Locate the removeable bowl plate on top of the Tripod, and thread the ball head onto the 3/8-16 stud, As shown in Fig 1 & 2 above
2. After the ball head is tight on the bowl plate, using the set screw on the bottom of the bowl plate tighten against ball head. As shown above in Fig. 2
3. Do not overtighten

Ball Head Locking Knob (As shown in Fig. 4)

This knob is to lock the main Ball from moving in any direction.

Fluid Pan Locking Knob (As shown in Fig. 3)

This knob is to pan the entire ball head in 360 degree motion.

Accessory Locking Knob (As shown in Fig. 4)

This knob is used to tighten accessories to the arca mount on top the ball head.

Ball Friction Control Knob (As shown in Fig. 3)

This knob is to control the friction of the main ball.

Note: Having this too tight can cause ball head to not move very well when the Ball head locking knob is in the free position.

Accessory Mounting Plate (As shown in Fig. 5)

This is used if you want to mount binoculars, camera or other acc.

